

CORVETTE C8 HIGH/RACE WING | INSTALLATION BASIC GUIDELINES

Components included:

- 1x Main Wing Blade
- 2x End Caps
- 1x Side Upright – for Driver Side
- 1x Side Upright – for Passenger Side
- 2x Middle Uprights

Hardware included:

- A) 2x 6" long bolts - 1/4" x 20 thread
- B) 2x 5 1/2" long bolts - 1/4" x 20 thread
- C) 2x 4 1/2" long bolts - 1/4" x 20 thread
- D) 6x 1/4" washers
- E) 4x nuts - 1/4" x 20 thread
- F) 4x 1" long Button head bolts - 1/4" x 20 thread
- G) 2x Angle Adapters
- H) 10x 1/4 spring washers

STEPS:

- Install the side uprights to the wing blade using the 4 1/2" long bolts and a spring washer through the upright's front orifice.
- Install the 2 middle uprights to the wing blade by using 5 1/2" long bolts using the upright's single orifice.
NOTE: Make sure to place a spring washer on the head of each bolt to prevent the tip of the bolt from making contact with the top surface of the wing blade while tightening the bolt, this helps prevent any damage on the wing blade. **Additional washers can be used as shims if needed.**
- Place the wing blade with uprights on the rear bumper cover, making sure that the threaded studs that stick out at the bottom of each upright go through the rear bumper cover's pre-drilled holes.

From underneath the rear bumper cover:

- Place a regular washer followed by a spring washer and a nut on the threaded stud coming out from each of the middle uprights.
- Place 1 Angle Adapter, lining up both orifices of the adapter with the orifices of one of the Side Uprights. - Secure the front orifice of the adapter by placing it through the threaded stud and secure it with a washer, spring washer and nut.
- Secure the rear orifice of the Angle Adapter by placing a 6" long bolt through the orifice and in to the wing blade's threaded insert. Make sure that the 6" long bolt has a regular washer and spring washer placed on the head so it locks in to the Angle Adapter's rear orifice.
- Install the Side End Caps on the Main Wing Blade using the Button Head Bolts.

NOTE: The Rear Bumper cover needs to be removed in order to install the wing with uprights.

CENTER UPRIGHT

NOTE: Additional spring washers may be required in this area to serve as shims, this helps prevent the tip of the long bolt from making contact with the top layer of the wing blade when being tightened.



Standard washer



Spring washer



Nut

SIDE UPRIGHT



NOTE: Standard washer, Spring washer and Nut illustrated above secures the threaded stud from underneath the adapter.